



selva sky


SV PSF8, SV PSF12, SV PSF16, SV PSFD12

installation manual




bejot:

1




2




x4

3



x4

4




x4

5




x4

6




x4

7




x4




PEOPLE



ADDITIONAL TOOLS




ATTACHED




x4

* – not added for assembly,
parts suitable for the ground

1




2




3




I





II




III




4




5




6






7




8


I





II





9



10







12

dimensions


SV PSFD12




SV PSF8



SV PSF12



SV PSF16



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 12/2021